


Low Pressure Fan



Legend Spare Parts List Low Pressure-Fan

Position No.	description
10	housing complete
20	fan wheel
30	inlet nozzle
40	suction wire mesh guard
50	motor flange
60	motor complete

1. Ordering instructions for spare parts

A clear identification and naming of the parts ensures the delivery of the correct spare part. To avoid delivery errors and extensive description, only specify the terms and numbers listed in the parts list.

Order address:

Set up your spare parts orders:

FA. Karl Klein Ventilatorenbau GmbH
Waldstraße24
D-73773 Aichwald
Tel.: 0711 – 36906-0
Fax.: 0711 – 36906-50